



**RUST  
BUSTER**  
FRAMEWORKS

**RB8629L & RB8629R**

**2000-2006 Toyota Tundra  
Front Body Mount**



**REQUIRED TOOLS**

Jack Stands or Lift  
Mig Welder  
Paint/Primer  
Locking Pliers  
Hand Grinder  
Cutting Wheel or Torch  
Welding Gloves  
Welding Hood/Shield  
Ear & Eye Protection  
Sockets & Ratchet  
Fire Extinguisher

**KIT CONTAINS**

Front Body Mount  
M10 Flanged Hex Bolt

**QTY**

1  
2



# RUST BUSTER

F R A M E W O R K S

## RB8629L & RB8629R

### 2000-2006 Toyota Tundra Front Body Mount

#### 1) PREPARING YOUR VEHICLE

Begin by disconnecting your battery prior to starting your installation.

Inspect your vehicle for leaking fuel lines, fuel tank and engine components. If you have fuel leaks repair all leaks prior to starting your installation. If your fuel tank is near your welding area **remove your tank prior to welding.**

Remove all combustible items above the work area such as seats, carpets, padding, etc.

**Keep all flammable materials away from the vehicle work area.**

#### 2) PREPARING YOUR WORKSTATION

Keep a fire extinguisher close by in the case of fire and make sure you always have a designated "Fire Watch" to assist during the cutting or welding phases.

Abide by all apprenticed welding safety standards and practices.

Always use appropriate welding eye protection, ear protection, and work and fire safety gloves during the installation and within the work area.



#### WARNING!

If you are unsure on how to perform the installation or how to operate any of the required tools listed above, it is **HIGHLY** advised that you enlist the work of a certified welder/installer.

Failure to follow proper safety precautions and instructions may result in serious injury. **The user assumes all liability when installing the product.**



# RUST BUSTER

F R A M E W O R K S

## RB8629L & RB8629R

### 2000-2006 Toyota Tundra Front Body Mount

#### 3) PREPARE YOUR VEHICLE

Mark off the location of the factory mount so as to use as a reference for the install.

Remove the body mount bolts and bushing.



#### 4) CUT

Begin cutting the body mount off.



Clean and grind the rail free of rust and debris, revealing bare metal. Then spray the work area with a weldable primer to help prevent further rust development.



#### 5) WELD

Remove any potential fire hazards from the work area. Tac weld the part to the frame. Following proper welding procedures, begin welding the part. 100% weld around all edges.



Spray the part with a primer to help prevent against further rust development.